



VeriMark Windows 11 Optional Update

Install the driver through Windows 11 Update


1. Right click on the Windows icon and select **Settings**.




2. Go to **Windows Update**.




3. **Make sure your Windows 11 is up to date.** If not, please install all updates first or you might not see the VeriMark driver appear on the update list.




4. Once you make sure all the updates are installed, click **"Advanced options"**.




5. Click **"Optional updates"**.




6. Click **"Driver updates"**.



7. Select **"Synaptics Incorporated - Biometric"**, and click **"Download & Install"**. The system will automatically download the VeriMark driver and install it.




8. Kensington fingerprint key will show on device manager.




VeriMark™ Windows 11 (Windows Hello) Setup Guide


1. Click on **Start** on the taskbar and click on **Settings**.




2. Click on **Accounts** to show sign in options.




3. Click on **Sign-in options**.




4. Alternatively, you can click on the **magnifier glass** on the taskbar and search for **"Windows Hello"**.




5. Click on **Fingerprint recognition (Windows Hello)** and **Set up**.




6. On the next window click on **Get Started**.




7. If it is the first time using Windows Hello, you need to add a security PIN. Enter a security key PIN then click OK for next step.




8. Once PIN has been set up enter it on the **Windows Hello setup**.



9. **Touch** the fingerprint sensor area repeatedly.



10. **Continue lifting and touching** the sensor to read fingerprint.



11. Click **Close** to finish fingerprint enrollment or **Add another finger** to set up another fingerprint.

12. To remove the fingerprint from the USB dongle click on **remove**.

