

Kensington[®]




MK7500F QuietType™ Pro Silent Mechanical Keyboard – Wireless (Full)























Show the current channel | Afficher la chaîne actuelle | Aktuellen Kanal anzeigen | Mostra il canale corrente | Mostrar el canal actual | Mostrar o canal atual | はいまい | 現在のチャンネルを表示する | 显示当前信号通道 |











Requires a minimum of 5V/1A (5W) of USB power to properly charge the keyboard. | Nécessite une alimentation USB de minimum 5 V/1 A (5W) USB pour correctement charger le clavier. | Zum ordnungsgemäßen Aufladen der Tastatur ist ein USB-Anschluss mit einer Ausgangsleistung von mindestens 5 V/1 A (5 W) erforderlich. | Per caricare correttamente la tastiera, è necessaria un'alimentazione USB di almeno 5 V/1 A (5 W). | Requiere una alimentación USB de un mínimo de 5 V/1 A (5 W) para cargar el teclado adecuadamente. | Requer um mínimo de 5 V/1 A (5 W) de potência USB para carregar corretamente o teclado. |

| ينطلب ما لا يقل عن 5 فولت/1 أمير (5 واط) من طاقة USB لشحن لوحة المفاتيح بشكل صحيح. | キーボードを正しく充電するには、5V/1A(5W)以上のUSB電力が必要です。 | 为键盘充电至少需要最低 5V/1A(5W)的USB 电源。











Mute On/Off | Mode muet activé/désactivé | Stummschaltung ein/aus | Attivazione/disattivazione dell'audio | Silenciar/Activar sonido | Silenciar/Colocar som | فالمون تشغیل کم الصوت | ミュートオン/オフ | 静音开/关 |



Camera On/Off | Caméra activée/désactivée | Kamera ein/aus | Attiva/disattiva telecamera | Cámara encendida/ apagada | Ligar/Desligar câmara | اتشغيل/ايقاف تشغيل الكاميرا カメラオン/オフ | 相机开/关 |



Answer Call | Répondre à l'appel | Anruf annehmen | Accetta chiamata | Responder Ilamada | Atender chamada | الرد على مكالة | 着信への応答 | 应答呼叫 |




End Call | Mettre fin à l'appel | Anruf beenden | Termina chiamata | Finalizar llamada | Terminar chamada | | 通話の終了| 结束呼叫 |

To customize your keyboard further, download Kensington Konnect™ for Keyboards. |
Pour personnaliser davantage votre clavier, téléchargez Kensington Konnect™ pour
claviers. | Um Ihre Tastatur weiter anzupassen, laden Sie Kensington Konnect™ für
Tastaturen herunter. | Per personalizzare ulteriormente la propria tastiera, scaricare
Kensington Konnect™ per tastiere. | Descargue Kensington Konnect™ para teclados
para personalizar el teclado. | Para personalizar ainda mais o seu teclado, transfira o
Kensington Konnect™ para teclados. |

إ إجراء مزيد من التخصيص للوحة المفاتيح لديك، فم بتنزيل "Kensington Konnect™ للوحات المفاتيح. キーボードをさらに細かくカスタマイズするには、キーボードにKensington Konnect™ をダウンロードしてください。 | 如要进一步自定义键盘,请为键盘下载 Kensington Konnect™。 |






	Windows	Mac
æ	Calculator Calculatrice Taschenrechner Calcolatrice Calculadora Calculadora الآلة الحاسبة 計算機 计算器	*
Q	Search Chercher Suche Ricerca Buscar Procurar بحث 検素 援素	
Fa.	Show Desktop Afficher le bureau Desktop anzeigen Mostra desktop Mostrar escritorio Mostrar Ambiente de Trabalho إظهار سطح المكتب デスクトップを表示 显示桌面	
6	Screen Shot Capture d'écran Screenshot Screenshott Captura de pantalla Captura de ecrã لقطة شاشة スクリーンショット 截屏	


^{*}Requires Kensington Konnect | *Nécessite Kensington Konnect |


^{*}Erfordert Kensington Konnect | *Richiede Kensington Konnect |

^{*}Requiere Kensington Konnect | *Requer o Kensington Konnect |












Fn + F6 I ⋖ ◀	Back Face arrière Rückseite Indietro Atrás Retroceder اللوحة الخلفية バック 后退	
Fn + F7 ▶II	Play/Pause Lecture/Pause Abspielen/Pause Riproduci/Pausa Reproducir/Pausar Reproduzir/Colocar em Pausa تشغيل/إيقاف مؤقت 再生/一時停止 播放/暂停	
Fn + F8 ▶▶I	Forward Commande d'avance Vorwärts Avanti Adelante Avançar التالي フォワード 前进	
Fn + F9 ◀ ×	Mute Speaker Désactiver le haut-parleur Lautsprecher stummschalten Disattivazione dell'altoparlante Silenciar altavoz Silenciar altifalante ﮐﺘﻢ ﺻﻮﺕ ﺍﻟﺴﻤﺎﻋﺎﺕ スピーカーをミュートする 扬声器静音	
Fn + F10 ■)	Decrease Volume Réduire le volume Lautstärke verringern Diminuzione del volume Bajar volumen Diminuir volume 音量を下げる 调低音量	
Fn + F11 ◄»))	Increase Volume Augmenter le volume Lautstärke erhöhen Aumento del volume Subir volumen Aumentar volume فع مستوى الموت 音量を上げる 调高音量	





- EN Download Kensington Konnect™ today: www.Kensington.com/Konnect
- Kensington Konnect™ noch heute herunterladen: www.Kensington.com/Konnect
- FR Téléchargez Kensington Konnect™ dès aujourd'hui : www.Kensington.com/Konnect
- Scarica subito Kensington Konnect™: www.Kensington.com/Konnect
- ES Descargue ya Kensington Konnect™: www.Kensington.com/Konnect
- PT Descarregue hoje o Kensington Konnect™: www.Kensington.com/Konnect
- Www.Kensington.com/Konnect :اليوم ™Kensington Konnect بادر بتنزيل برنامج
- CN 立即下载 Kensington Konnect™: www.Kensington.com/Konnect
- JP 今すぐKensington Konnect™ をダウンロードしてください: www.Kensington.com/Konnect







Looking for support? Visit us online at: http://kensington.com/QuietType-Keyboard-Support



Kensington® and QuietType™ are trademarks of ACCO Brands. macOS is a trademark of Apple Inc. registered in the U.S. and other countries. Windows is a registered trademark of Microsoft Corporation in the U.S. and/or other countries. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG,Inc. and any use of such marks by Kensington Computer Products Group is under license. All other registered and unregistered trademarks are the property of their respective owners.

© 2023 Kensington Computer Products Group, a division of ACCO Brands.

Patents: https://www.accobrands.com/patents/