

KensingtonWorks™

for Windows

12/13/2019	(Official release version)
Version 2.1.08	<p>Add ProFit Ergo Wired Mouse.</p> <p>Add localization strings – “Scroll Right” and “Scroll Left”</p> <p>Fix the localization bug of detecting from system locale.</p> <p>Fix key chording bound “Scroll Left/Right”</p> <p>Increase font size.</p> <p>Fix MinimizeAll issue</p>
1/8/2020	
Version 2.1.10	<p>Fix Helper can't be resumed when remove from start up menu</p> <p>Fix Helper will be killed during uninstall process before user's confirmation.</p> <p>Fix Single axis malfunction when use same modifier key with Slow pointer</p> <p>Fix White side appear when changing resolution</p> <p>Fix UI partition is not right under low resolution with 125% size of text</p> <p>Add localization of the balloon message of kwdwnldr.</p> <p>Add Ergo Vertical Wireless Mouse.</p> <p>Update the image of Ergo Wired Mouse.</p> <p>Update tutor images.</p>
1/9/2020	
Version 2.1.11	<p>Update Win 7 BLE devices hardware IDs and Win 7 driver</p>
2/24/2020	
Version 2.1.13	<p>Driver update: add Bluetooth 3.0 HID's for new dual-mode trackball/mouse.</p> <p>Erasing the cache file “Settings” will lose the record of bind to cloud.</p> <p>Fix Can't log in Google Drive when user selects “Bind to Cloud”</p>
2/25/2020	
Version 2.1.14	<p>Feature change: define “second drag action” as “drag release”.</p> <p>Change backup restore success message icon</p>
3/20/2020	
Version 2.1.15	<p>Add feature: Track Scroll.</p> <p>Remove TAU (test automation) commands “emulateButtonClick” & “emulateButtonPress” from release build for security concern.</p>

4/9/2020

Version 2.1.16

Update "Copyright © 2020 ACCO Brands LLC."
Add shortcut supported keys: backspace, arrowdown, arrowup.
Fix Single axis and slow pointer can't work normal when set different modifier key

5/15/2020

Version 2.1.17

Fix post keystroke bug for "Pro Tools"
Update translation json files for "ja" & "zh-TW". (Japan & Traditional Chinese)

6/5/2020

Version 2.1.18

Add navigation feature - Auto Scroll.

- i. Click button to enable "Auto Scroll";
- ii. Click any button to disable "Auto Scroll";
- iii. Two scroll directions: horizontal and vertical.
- iv. Moving trackball to start "Auto Scroll" for 15 seconds (count down from the end of the moving of the trackball);
- v. During auto scrolling, "slightly/shortly" moving the trackball to change the direction will hold auto scroll;
- vi. During auto scrolling, normal moving the trackball to change the direction will change the direction of Auto scroll;
- vii. Limitation: for application specific setting for "Auto Scroll", "Track Scroll" can't be disabled by switch to another application until some button of the trackball is clicked.

Change UI flow:

- i. When launch KensingtonWorks, go to the trackball configure page directly if only single trackball is connected.
- ii. Go to the trackball configure page when a new trackball is plugged in.

9/15/2020

Version 2.1.19

Add Orbit Fusion Trackball support
Fix "Media control shortcut" bug of ver.2.1.18

10/31/2020

Version 2.2.2

1. Improve the button event handling algorithm.
2. Fix issue Navigation "HOME" "PAGE UP" malfunctioned
3. Fix issue Left key and right key can't be released after pressing simultaneously
4. Fix issue It takes two clicks to get the Left Drag to stick
5. Fix issue A combination of simultaneously pressed left and right trackball keys. Normally this simulates a middle mouse click, but it's often interpreted as a drag and drop operation.
6. Fix issue Redefine the behavior of Double / Triple click to be the same as the one of TrackballWorks.



All specifications are subject to change without notice. Products may not be available in all markets. Kensington and the ACCO name and design are registered trademarks of ACCO Brands. Kensington The Professionals' Choice is a trademark of ACCO Brands. All other registered and unregistered trademarks are the property of their respective owners. © 2020 Kensington Computer Products Group, a division of ACCO Brands. All rights reserved. k20-3416-us

Kensington

The Professionals' Choice™

FOR MORE INFORMATION CONTACT: 1-855-692-0054 | sales@kensington.com